Application Notes

How to open ZNV program in NV4

1) First, store a ZNV file in a HGDATA01 → NVDATA folder.

2) Launch NV4 software.

3) Click on Setup in NV4 and Select "External Memory Device" in Communication Settings.

4) Go to Online → Upload

5) Select the Drive → HGDATA01. Click OK to upload.